



T4 Lamps



MILLER LIGHTING PRODUCTS ELECTRONIC BALLASTS



For 26W - 42W Triple Lamps

Number Of Lamps	Input Volts	Lamp Start. method	MILLER Ballast Number	Input Power	Ballast Factor	Max. THD %	Line Current (Amps)	Min. Start Temp. (F / C)	Case Measure	Wiring Diagram	Symbols, Foot Notes	
CFTR26W/GX24q - 26W CFL Triple Tube												
1 Lamp	120-277	PS	BB26CMTHRP-C	30	1.00	10	0.25-0.11	0/-18	H	21	For Case measurements and Wiring diagrams data refer to APPENDIX	
	120-277	PS	BB26CMTHRP-W	30	1.00	10	0.25-0.11	0/-18	G	20		
2 Lamps	120-277	PS	BB26CMTHRP-C	58-56	0.97	10	0.48-0.21	0/-18	H	21		
	120-277	PS	BB26CMTHRP-W	58-56	0.97	10	0.48-0.21	0/-18	G	20		
CFTR32W/GX24q - 32W CFL Triple Tube												
1 Lamp	120-277	PS	BB26CMTHRP-C	36	0.98	10	0.31-0.13	0/-18	H	21		
	120-277	PS	BB26CMTHRP-W	36	0.98	10	0.31-0.13	0/-18	G	20		
CFTR42W/GX24q - 42W CFL Triple Tube												
1 Lamp	120-277	PS	BB26CMTHRP-C	46	0.98	10	0.38-0.17	0/-18	H	21		
	120-277	PS	BB26CMTHRP-W	46	0.98	10	0.38-0.17	0/-18	G	20		

ORDERING INFORMATION (SUFFIXES)

Note: For Standard applications Order NE (Normal Ballast Factor)

Miller Electronic Ballasts ARE Multi-Voltage (120V-277V)

- NE = (N) Normal Ballast Factor + (E) High Efficiency Designation
- HE = (H) High Ballast Factor + (E) High Efficiency Designation
- LE = (L) Low ballast Factor + (E) High Efficiency Designation

Lamp Starting Methods

- IS = INSTANT START
- RS = RAPID START
- PS = PROGRAM START

Additional Notes

- C = side terminals
- W = wire from behind



For Case measurements and Wiring diagrams data refer to APPENDIX