



T9 Circular



High-efficiency electronic ballasts

MILLER LIGHTING PRODUCTS ELECTRONIC BALLASTS

For 22W - 32WT9 Circular Lamps

Number Of Lamps	Input Volts	Lamp Start. method	MILLER Ballast Number	Input Power	Ballast Factor	Max. THD %	Line Current (Amps)	Min. Start Temp. (F/ C)	Case Measure	Wiring Diagram	Symbols, Foot Notes
-----------------	-------------	--------------------	-----------------------	-------------	----------------	------------	---------------------	---------------------------	--------------	----------------	---------------------

FC8T9 - 22W

22W - T9 Circular Lamps

1 Lamp	120-277	IS	BB32LMTNE	20	0.90	165	0.29	0/-18	C	52
2 Lamps	120-277	IS	BB32LMTNE	31	0.70	165	0.43	0/-18	C	51

FC12T9 - 32W

32W - T9 Circular Lamps

1 Lamp	120-277	IS	BB32LMTNE	28	0.90	165	0.39	0/-18	C	52
2 Lamps	120-277	IS	BB32LMTNE	43	0.70	165	0.61	0/-18	C	51

(1) FC8T9 - 22W & (1) FC12T9 - 32W T9 Circular Lamps

2 Lamps	120-277	IS	BB32LMTNE	37	0.70	165	0.52	0/-18	C	51
----------------	----------------	-----------	------------------	-----------	-------------	------------	-------------	--------------	----------	-----------

For Case measurements and Wiring diagrams data refer to APPENDIX

ORDERING INFORMATION (SUFFIXES)

Note: For Standard applications Order NE (Normal Ballast Factor)

Miller Electronic Ballasts ARE Multi-Voltage (120V-277V)

- NE = (N) Normal Ballast Factor + (E) High Efficiency Designation
- HE = (H) High Ballast Factor + (E) High Efficiency Designation
- LE = (L) Low ballast Factor + (E) High Efficiency Designation

Lamp Starting Methods

- IS = INSTANT START
- RS = RAPID START
- PS = PROGRAM START

Additional Notes

- C = side terminals
- W = wire from behind

For Case measurements and Wiring diagrams data refer to APPENDIX